

Piezo Stages

Linear Stages

Rotation Stages

ZF Stages

Motorized Optics Holders

Goniometers


GS Closed Loop Stages

Controllers & Drivers

Cables & Accessories

Software

## SGSP series System Diagram



ORDERING  
&  
TECHNICAL SUPPORT  
(949) 851-5881  
FAX (949) 851-5058  
E-MAIL  
sales@optosigma.com  
WEB  
www.optosigma.com